

POWERFLUX 4000 Technical Datasheet

# Electromagnetic flow sensor

- · Robust, fully welded construction
- · Constructed and tested for nuclear environments
- Full bore construction



The documentation is only complete when used in combination with the relevant documentation for the signal converter.



1	Product features		
20	1.1 The calling of the formula of the calling of th		
	1.1 The reliable solution for nuclear environments		
	1.2 Options		
	1.3 Measuring principle	6	
2	Technical data	7	
	2.1 Technical data	7	
	2.2 Measurement accuracy	11	
	2.3 Dimensions and weights	12	
3	Installation	15	
	3.1 Intended use	15	
	3.2 General notes on installation		
	3.2.1 Vibration		
	3.2.2 Magnetic field		
	3.3 Installation conditions		
	3.3.1 Inlet and outlet		
	3.3.2 Bends in 2 or 3 dimensions		
	3.3.3 T-section		
	3.3.4 Bends		
	3.3.5 Open feed or discharge		
	3.3.6 Pump		
	3.3.7 Control valve	18	
	3.3.8 Air venting and vacuum forces	19	
	3.3.9 Flange deviation	20	
	3.3.10 Mounting position		
	3.4 Mounting	21	
	3.4.1 Torques and pressures	21	
4	Electrical connections	24	
	4.1 Safety instructions	24	
	4.2 Grounding		
	4.3 Virtual reference for IFC 300 (W and F version)		
	4.4 Connection diagrams		
5	Notes	27	

### 1.1 The reliable solution for nuclear environments.

The **POWERFLUX 4000** is an electromagnetic flow sensor specifically constructed for radiation areas.

At the used materials for construction of the flow sensor are selected and tested to meet the demands for the use in nuclear environments.

The fully welded construction has proven itself with a huge track record of applications in the most hostile and demanding environments.



- Robust fully welded construction
- 2 Diameter range: DN2.5...DN1000
- 3 Hastelloy, titanium, tantalum, stainless steel, platinum and low noise electrodes
- Available with ETFE or PFA liner

# Highlights

- · Chemical resistant ETFE liner
- · Reliable and well proven construction
- · Constructed & tested for nuclear environments

### Industries

Nuclear

### **Applications**

- Cooling water
- · Transport water
- Borated water
- Spent resin
- Sea water

# 1.2 Options



The POWERFLUX 4000 is available from DN2.5 up to DN1000 with a large range of pressure ratings. Two signal converters can be combined with the POWERFLUX 4000: the powerful and high end IFC 300 and the fully analogue AFC 030 converter.

# 1.3 Measuring principle

An electrically conductive fluid flows inside an electrically insulated pipe through a magnetic field. This magnetic field is generated by a current, flowing through a pair of field coils. Inside of the fluid, a voltage U is generated:

U=v\*k\*B\*D

in which:

v = mean flow velocity

k = factor correcting for geometry

B = magnetic field strength

D = inner diameter of flowmeter

The signal voltage U is picked off by electrodes and is proportional to the mean flow velocity v and thus the flow rate Q. A signal converter is used to amplify the signal voltage, filter it and convert it into signals for totalizing, recording and output processing.




Figure 1-1: Measuring principle

- 1) Field coils
- 2 Magnetic field
- 3 Electrodes
- (a) Induced voltage [proportional to flow velocity]

# 2.1 Technical data

- The following data is provided for general applications. If you require data that is more relevant to your specific application, please contact us or your local sales office.
- Additional information (certificates, special tools, software,...) and complete product documentation can be downloaded free of charge from the website (Downloadcenter).

### Measuring system

Measuring principle	Faraday's law	
Application range	Electrically conductive fluids	
Measured value	di .	
Primary measured value	Flow velocity	
Secondary measured value	Volume flow	

#### Design

Features	Fully welded maintenance-free sensor.
	Flange version with full bore flow tube.
	Standard as well as higher pressure ratings.
	Broad range of nominal sizes.
	Industry specific insertion lengths.
Modular construction	The measurement system consists of a flow sensor and a signal converter. It is only available as a separate version.
Remote version	With AFC 030 converter: POWERFLUX 4030 W In field (F) version with IFC 300: POWERFLUX 4300 F
Nominal diameter	DN251000 / 140"

Measuring accuracy	
Maximum measuring error	These values are related to the pulse / frequency output.
	Related to volume flow [MV = Measured Value]
	With AFC 030 converter:
	DN2.5:1000 ± 1% of MV + 2.5 mm/s
	With IFC 300 converter:
	DN2.5:15 ± 0.3% of MV + 2 mm/s
	DN25:1000 ± 0.2% of MV + 1 mm/s
	The additional typical measuring deviation for the current output is $\pm 10~\mu A$ .
	The maximum measuring error depends on the installation conditions.
	For detailed information refer to refer to Measurement accuracy on page 11
Repeatability	±0.5% of MV, minimum 1 mm/s
Calibration	Standard:
	Two point calibration by direct volume comparison.
Long term stability	±0.3% of MV
Special calibration / Verification	On request.

# Operating conditions

Temperature	űr.	
Process temperature	ETFE: -40+120°C / -40+248°F	
	PFA: -40+180°C / -40+356°F	
Ambient temperature	Standard (with stainless steel connection box):	
	-40+55°C / -40+130°F	
Storage temperature	-50+70°C / -58+158°F	
Measurement range	-12+12 m/s / -40+40 ft/s	
Pressure		
EN 1092-1	DN200700: PN 10	
	DN65 and DN100150: PN 16	
	DN2.550 and DN80: PN 40	
	Other pressures on request.	
ASME B16.5	1/1024": 150 lb RF	
PORT STORMAGE WITH PROPERTY OF	Other pressures on request.	
JIS	DN501000: 10 K	
	DN2.540: 20 K	
	Other pressures on request.	
LVCSCACA OF BOARD	ETFE:	
Vacuum load	100 mbara (+40+120°C ), P <sub>max</sub> ; 150 bar	
	1.5 psia [+104+248°F], P <sub>max</sub> ; 2176 psi	
	PFA	
	0 mbara (+40+180°C ), P <sub>max</sub> ; 50 bar	
	0 psia (+104+356°F ), P <sub>max</sub> ; 725 psi	
Pressure loss	Negligible	

Chemical properties	- år	
Physical condition	Electrically conductive liquids	
Electrical conductivity		
	Other than water: ≥ 1 µS/cm	

# Installation conditions

Installation	Assure that the flow sensor is always fully filled.
	For detailed information refer to Installation on page 15
Flow direction	Forward and reverse.
	Arrow on flow sensor indicates positive flow direction.
Inlet run	≥5 DN
Outlet run	≥ 2 DN
Dimensions and weights	For detailed information refer to Dimensions and weights on page 12

### Materials

Sensor housing	Standard: Stainless steel
	Other materials on request.
Measuring tube	Austenitic stainless steel
Flanges	Standard: Stainless steel
	Other materials on request.
Liner	Standard:ETFE, DN251000
	Option:PFA, DN2.515
Protective coating	On exterior of the meter: flanges, housing, signal converter (compact version) and / or connection box (field version)
	Standard: siloxane coating
	according: ISO 12944-2 :2007 Category 3, Medium / C4 Low
Connection box	Stainless steel
Measuring electrodes	Standard: Hastelloy® C
	Option: Platinum, stainless steel, titanium, tantalum, low noise
	Other materials on request.
Grounding rings	Standard : Stainless steel
	Option: Hastelloy® C, titanium, tantalum
	Grounding rings can be omitted with virtual reference option for the IFC 300 converter.
Reference electrode (optional)	Standard: Hastelloy® C
	Option: Platinum, stainless steel, titanium, tantalum, low noise
	Other materials on request.

### Process connections

Flange		
EN 1092-1	DN2.51000 in PN 640	
ASME	1/1040" in 150900 lbs RF	
JIS	DN2.51000 in JIS 1020 K	
Design of gasket surface	RF	
	Other sizes or pressure ratings on request.	

Electrical connections	
Signal cable	
Type A (DS and DS-L)	In combination with the IFC 300 and AFC 030 signal converter
	Standard cable, double shielded.  Max. length: 600 m / 1950 ft (dep. on electrical conductivity and measuring sensor).
	For detailed information refer to the documentation of the relevant signal converter.
Type B (BTS)	In combination with the IFC 300 signal converter
	Optional cable, triple shielded.  Max. length: 600 m / 1950 ft (dep. on electrical conductivity and measuring sensor).
	For detailed information refer to the documentation of the relevant signal converter.
1/0	For full details of I/O options, including data streams and protocols, see the technical data sheet of the relevant signsal converter.
Others	For detailed information of the connection cables of the AFC 030 see the manual of the signal converter.

Approvals and certificates	
CE	
This device fulfills the statutory testing of the product by applyi	requirements of the EU directives. The manufacturer certifies successful ng the CE mark.
	For full information of the EU directives & standards and the approved certifications, please refer to the CE declaration or the manufacturer website.
Nuclear approvals	10 Gr
EMC	IEC 61000-4
Radiation	ETFE: TID 5E+06 Rad
	PFA: TID 1E+06 Rad
Vibration	EN 60068-2-6
Seismic	IEC 60980 - 1989 ( 300 m/s²)
Fire	Nf C32-070: C1 (on request, for non-standard cably only)
Other approvals and standards	
Protection category acc. to	Standard:
IEC 529 / EN 60529	IP 66/67 (NEMA 4/4X/6)
Vibration resistance	IEC 68-2-64
Random vibration test	IEC 68-2-34
Shock test	IEC 68-2-27

# 2.2 Measurement accuracy

Every electromagnetic flowmeter is calibrated by direct volume comparison. The wet calibration validates the performance of the flowmeter under reference conditions against accuracy limits.

The accuracy limits of electromagnetic flowmeters are typically the result of the combined effect of linearity, zero point stability and calibration uncertainty.

#### Reference conditions

- · Medium: water
- Temperature: +5...35°C / +41...95°F
- Operating pressure: 0.1...5 barg / 1.5...72.5 psig
- Inlet section: ≥ 5 DN
- Outlet section: ≥ 2 DN

#### IFC 300 accuracy




Figure 2-1: X [m/s] : flow velocity

Y [%]: deviation from the actual measured value (mv)

#### AFC 030 accuracy





Figure 2-2: X [m/s] : flow velocity

Y [%]: deviation from the actual measured value (mv)

- ① Minimal accuracy for DN10...1000
- ② Minimal accuracy for DN2.5...6

# 2.3 Dimensions and weights



- The value may vary depending on the used cable glands.
- All data given in the following tables are based on standard versions of the flow sensor only.
- Especially for smaller nominal sizes of the flow sensor, the signal converter can be bigger than the flow sensor.
- Note that for other pressure ratings than mentioned, the dimensions may be different.
- For full information on signal converter dimensions see relevant documentation.

#### EN 1092-1

	Dimensions [mm]			Nominal size		
Approx.				L	22 0	
weight [kg]	W	н	EFTE	PFA	PN [bar]	DN
3	90	142	-	130	40	2.56
6	90	106	145	130 ①	40	10
6	95	106	-	130 ①	40	15
4	115	140	200	22	40	25
5	140	157	250		40	32
5	150	166	250		40	40
9	165	186	250		40	50
9	185	200	250	22	16	65
12	200	209	250		40	80
15	220	237	250		16	100
19	250	266	300	•	16	125
27	285	300	300	2	16	150
34	340	361	350		10	200
48	395	408	400	2	10	250
58	445	458	500		10	300
78	505	510	500	25	10	350
101	565	568	600		10	400
111	615	618	600	E	10	450
130	670	671	600	-	10	500
165	780	781	600	27	10	600
248	895	898	700		10	700
331	1015	1012	800		10	800
430	1115	1114	900		10	900
507	1230	1225	1000	20	10	1000

# 150 lb flanges

Nomina	al size		Dimer	Dimensions [inches]		
ASME	PN [psi]	L		н	w	Approx. weight [lb]
		PFA	ETFE			
1/10 1/4	284	5.12	150	5.59	3.50	6
3/81/2	284	5.12 ①	(5)	5.08	3.50	6
3/4	284	5.91	-	5.28	3.50	6
1"	284	-	7.87	5.39	4.25	7
1 1/4"	284	15	9.84	5.98	4.62	7
1 1/2"	284	-	9.84	6.10	5.00	11
2"	284	12	9.84	7.05	5.98	18
2 1/2"	284	-	9.84	7.72	7.00	24
3"	284	18	9.84	8.03	7.50	26
4"	284	-	9.84	9.49	9.00	40
5"	284	18	11.81	10.55	10.0	49
6"	284	-	11.81	11.69	11.0	64
8"	284	98	13.78	14.25	13.5	95
10"	284	-	15.75	16.3	16.0	143
12"	284	18	19.69	18.78	19.0	207
14"	284	-	27.56	20.67	21.0	284
16"	284	95	31.50	22.95	23.5	364
18"	284	-	31.50	24.72	25.0	410
20"	284	15	31.50	26.97	27.5	492
24"	284	-	31.50	31.38	32.0	675

- Pressures at 20°C / 68°F.
- For higher temperatures, the pressure and temperature ratings are as per ASME B16.5.

# 300 lb flanges

Nomina	al size	I	Dimensions	[inches]		
ASME	PN [psi]	L		н	w	Approx. weight [lb]
		PFA	ETFE			
1/101/4	741	5.12	1970	5.59	3.75	6
3/81/2	741	5.12 ①	350	5.24	3.75	6
3/4	741	5.91	-	5.67	3.75	6
1"	741	*	9.84	5.71	4.87	11
1 1/2"	741	17.	11.81	6.65	6.13	13
2*	741	-	11.81	7.32	6.50	22
3"	741	18	11.81	8.43	8.25	31
4"	741	+	11.81	10.00	10.0	44
6"	741	18	13.78	12.44	12.5	73
8"	741	-	15.75	15.04	15.0	157
10"	741	15	19.69	17.05	17.5	247
12"	741	*	23.62	20.00	20.5	375
14"	741	18	27.56	21.65	23.0	474
16"	741	-	31.50	23.98	25.5	639
20"	741	15	31.50	28.46	30.5	937
24"	741	*	31.50	33.39	36.0	1345

- Pressures at 20°C / 68°F.
- For higher temperatures, the pressure and temperature ratings are as per ASME B16.5.

#### 3.1 Intended use

Responsibility for the use of the measuring devices with regard to suitability, intended use and corrosion resistance of the used materials against the measured fluid lies solely with the operator.

The manufacturer is not liable for any damage resulting from improper use or use for other than the intended purpose.

The measurement of volumetric flowrate of electrically conductive fluids. Basic measurement is the flow velocity upon which all other measurements are based.

### 3.2 General notes on installation

Inspect the packaging carefully for damages or signs of rough handling. Report damage to the carrier and to the local office of the manufacturer.

Do a check of the packing list to make sure that you have all the elements given in the order.

Look at the device nameplate to ensure that the device is delivered according to your order. Check for the correct supply voltage printed on the nameplate.

#### 3.2.1 Vibration




Figure 3-1: Avoid vibrations

## 3.2.2 Magnetic field




Figure 3-2: Avoid magnetic fields

### 3.3 Installation conditions

Install in a slightly descending pipe section to prevent air from collecting and to avoid faulty measurements (meter can drain).

#### 3.3.1 Inlet and outlet




Figure 3-3: Recommended inlet and outlet

- ① Refer to chapter "Bends in 2 or 3 dimensions"
- (2) ≥ 2 DN

#### 3.3.2 Bends in 2 or 3 dimensions




Figure 3-4: Inlet when using 2 and/or 3 dimensional bends in front of the flowmeter

Inlet length: using bends in 2 dimensions: ≥ 5 DN; when having bends in 3 dimensions: ≥ 10 DN

### 3.3.3 T-section




Figure 3-5: Distance behind a T-section

① ≥ 10 DN

### 3.3.4 Bends




Figure 3-6: Installation in bending pipes




Figure 3-7: Installation in bending pipes

Avoid draining or partial filling of the flow sensor

# 3.3.5 Open feed or discharge




Figure 3-8: Installation in front of an open discharge

# 3.3.6 Pump




Figure 3-9: Installation behind a pump

① Inlet: ≥3 DN

### 3.3.7 Control valve



Figure 3-10: Installation in front of a control valve

# 3.3.8 Air venting and vacuum forces




Figure 3-11: Air venting

- ① ≥5 m ② Air ventilation point




Figure 3-12: Vacuum

① ≥5 m

# 3.3.9 Flange deviation

Max. permissible deviation of pipe flange faces:  $L_{max} - L_{min} \le 0.5 \text{ mm} / 0.02^{\circ}$ 




Figure 3-13: Flange deviation

- ① L<sub>max</sub>
- ② Lmin

# 3.3.10 Mounting position




Figure 3-14: Mounting position

- · Mount flow sensor either with signal converter aligned upwards or downwards.
- · Install flow sensor in line with the pipe axis.
- · Pipe flange faces must be parallel to each other.

# 3.4 Mounting



#### CAUTION!

Please take care to use the proper gasket to prevent damaging the liner of the flowmeter. In general, the use of spiral wound gaskets is not advised, as it could severely damage the liner of the flowmeter.

### 3.4.1 Torques and pressures




Figure 3-15: Tightening of bolts

### Tightening of bolts

- · Always tighten the bolts uniformly and in diagonally opposite sequence.
- Do not exceed the maximum torque value.
- Step 1: Apply approx. 50% of max. torque given in table.
- . Step 2: Apply approx. 80% of max, torque given in table.
- · Step 3: Apply 100% of max. torque given in table.

Other sizes / pressure ratings on request.

re J	Nominal size DN [mm]	Bolts	Max. torque [Nm] ①
PN 40	2.56	4 x M 1	2 32
PN 40	10	4 x M 1	2 7.6
PN 40	15	4 x M 1	2 9.3
PN 40	25	4 x M 1	2 22
PN 40	32	4 x M 1	6 37
PN 40	40	4 x M 1	6 43
PN 40	50	4 x M 1	6 55
PN 16	65	4 x M 1	6 51
PN 40	65	8 x M 1	6 38
PN 40	80	8 x M 1	6 47
PN 16	100	8 x M 1	6 39
PN 16	125	8 x M 1	6 53
PN 16	150	8 x M 2	0 68
PN 10	200	8 x M 2	0 84
PN 16	200	12 x M 2	0 68
PN 10	250	12 x M 2	0 78
PN 16	250	12 x M 2	4 116
PN 10	300	12 x M 2	0 88
PN 16	300	12 x M 2	4 144
PN 10	350	16 x M 2	0 97
PN 10	400	16 x M 2	4 139
PN 10	450	20 x M 2	4 127
PN 10	500	20 x M 2	4 149
PN 10	600	20 x M 2	7 205
PN 10	700	20 x M 2	7 238
PN 10	800	24 x M 3	0 328
PN 10	900	28 x M 3	0 308
PN 10	1000	28 x M 3	5 392

The specified torque values are dependent on variables (temperature, bolt material, gasket material, lubricants, etc.) which are not within the control of the manufacturer. Therefore the values should be regarded as indicative only.

Values are based on: F= ASTM gr B7 Studbolts - F=0.14 - Carbon steel flanges

Max. torque [in-lb] (1	Bolts	Flange class [lb]	Nominal size [inch]
39	4 x 1/2"	150	1/10 3/8 1/4 , ¾
34	4 x 1/2"	150	1/2
50	4 x 1/2"	150	3/4
67	4 x 1/2"	150	1
97	4 x 1/2"	150	1 1/4
138	4 x 1/2"	150	1 1/2
225	4 x 5/8"	150	2
43	4 x 5/8"	150	3
34	8 x 5/8"	150	4
6	8 x 3/4"	150	6
979	8 x 3/4"	150	8
1104	12 x 7/8"	150	10
1478	12 x 7/8"	150	12
1835	12 x 1"	150	14
1767	16 x 1"	150	16
2605	16 x 1 1/8"	150	18
2365	20 x 1 1/8"	150	20
3419	20 x 1 1/4"	150	24
2904	28 x 1 1/4"	150	28
4560	28 x 1 1/2"	150	32
2	32 x 1 1/2"	150	36
2	36 x 1 1/2"	150	40

The specified torque values are dependent on variables (temperature, bolt material, gasket material, lubricants, etc.) which are not within the control of the manufacturer. Therefore the values should be regarded as indicative only.

Values are based on: F= ASTM gr B7 Studbolts - F=0.14 - Carbon steel flanges

Other sizes / pressure ratings on request.

- Pressures are applicable at 20°C / 68°F.
- For higher temperatures, the pressure ratings are as per ASME B16.5.

<sup>(2)</sup> Information \*; please contact the support service department

# 4.1 Safety instructions

All work on the electrical connections may only be carried out with the power disconnected. Take note of the voltage data on the nameplate!

Observe the national regulations for electrical installations!

Observe without fail the local occupational health and safety regulations. Any work done on the electrical components of the measuring device may only be carried out by properly trained specialists.

Look at the device nameplate to ensure that the device is delivered according to your order. Check for the correct supply voltage printed on the nameplate.

# 4.2 Grounding

The device must be grounded in accordance with regulations in order to protect personnel against electric shocks.




Figure 4-1: Grounding

① Metal pipelines, not internally coated. Grounding without grounding rings.




Figure 4-2: Different types of grounding rings

- Grounding ring number 1
- ② Grounding ring number 2
- ③ Grounding ring number 3

### Grounding ring number 1:

thickness: 3 mm / 0.1" (tantalum: 0.5 mm / 0.02")

### Grounding ring number 2:

- thickness: 3 mm / 0.1"
- · Prevents damage to the flanges during transport and installation
- · Especially for flow sensors with PTFE liner

### Grounding ring number 3:

- thickness: 3 mm / 0.1"
- With cylindrical neck (length 30 mm / 1.25" for DN10...150 / 3/8...6")
- · Offers liner protection against abrasive fluids

# 4.3 Virtual reference for IFC 300 (W and F version)




Figure 4-3: Virtual reference

### Minimum requirements:

- Size: ≥ DN10
- Electrical conductivity: ≥ 200 µS/cm
- Signal cable: max. 50 m / 164 ft, type DS

# 4.4 Connection diagrams

For the connection diagrams please refer to the documentation of the applicable signal converter.



#### KROHNE - Process instrumentation and measurement solutions

- Flow
- Level
- Temperature
- Pressure
- Process Analysis
- Services

Head Office KROHNE Messtechnik GmbH Ludwig-Krohne-Str. 5 47058 Duisburg (Germany) Tel.: +49 203 301 0

Fax: +49 203 301 10389 info@krohne.com

The current list of all KROHNE contacts and addresses can be found at: www.krohne.com

